Care instruction luxury vinyl flooring Perform

Floors in commercial areas - sorted by manufacturer / ter Hürne / Soya Design Vinyl / Perform / Office & Hospitality / Maintenance Guide / Instruction



Preventive Measures

In the entrance area it is necessary to establish clean-walking zones, in which sufficiently large and effective floor mats must be laid, which must also be regularly cleaned or exchan-ged. This prevents a great deal of dirt from being walked into the building and reduces the mechanical wear on the floor.

Chairs with defective or missing chair-gliders, as well as unsuitable castors destroy not only the surface protection but also the floor covering itself and are therefore to be avoided. We urgently recommend fitting suitable chair or furniture gliders (e.g. scratchnomore, www.

https://www.dr-schutz.com/scratchnomore), or alternatively soft chair/furniture castors (Type W according to German norms DIN EN 12528 and 12529).

In areas of high specific loads, we recommend providing additional suitable protection, e.g. we recommend polycarbonate mats under hand disinfectant dispensers and tyres.

Post-installation cleaning

To remove dirt and remnants of laying and construction work, the newly laid floor covering must undergo post-installation cleaning before use.

For this purpose use the recommended cleaner in the respective dilution. In the case of minor dirt caused by construction, reduce the concentration according to the degree of soiling. Mop the floor clean in two stages with well-squeezed mop-covers. To remove sticky stains which cannot be removed by mopping, use a type SRP Monodisc machine with a red pad in the spray-cleaner-process, or use a wet-suction vacuum-cleaner (e.g. Dr.Schutz wet-suction vacuum-cleaner PS27). Subsequently neutralize the floor with clear water (well-squeezed mop-covers or Premium F2). Generally avoid pools forming.

Recommended Cleaners:

PU Cleaner, 1:10

Daily Cleaning

Removal of dust: remove loose dirt and dust using a slightly damp mop

Manual wet cleaning or by machine

For the removal of sticky stains, dilute the recommended cleaner as specified and clean the floor as follows:

• depending on the level of dirt, clean the floor in one or two stages with a suitable, well-pressed out mop

Dr. Schutz'GROUP

(e.g. the Professional Mop System).

Recommended cleaners:

PU Cleaner

Recommended dilution:

1:200

Machine Cleaning/interim cleaning

If sticky stains cannot be removed by manual mopping, we recommend carrying out machine cleaning with the recommended cleaner, diluted with water in a ratio corresponding to the degree of soiling, using a scrubbing/cleaning machine, or monodisc-machine SRP and red superpad in the Cleaner-process (on floors laid without adhesive). This process is also suitable for interim cleaning at regular intervals.

Recommended cleaners:

PU Cleaner

Recommended dilution:

1:50-1:100

Removing stains, heel marks & scratches

Stubborn stains and rubber heel marks, which cannot be removed during day-to-day maintenance, can be eliminated by using our recommended product with a cloth or scratch-free pad. Subsequently mop the floor with clear water. Remove stains as speedily as possi-ble, as certain kinds of stain migrate into the floor over time and can then only be removed with difficulty or incompletely.

Recommended Products:

PU / Waxnomor Cleaner, concentrated

Elatex

Strip-Cleaning

Strip-cleaning of the floor covering is deemed necessary:

in order to remove stubborn stains and residues which cannot be removed by day-to-day maintenance cleaning.

For this purpose spray Clean & Strip in the recommended dilution onto the floor and, after allowing it to soak in for the stipulated time, use the recommended tools, appliances and pads to scrub it. Avoid pools forming.

Recommended Cleaners:

Clean & Strip, undiluted up to 1:5 with water

Soak-in time

Dr. Schutz GROUP

Soak-in time: up to 5 minutes, depending on the stubbornness of the residues which are to be removed

Recommended Pad:

Red Superpad, gritbrush red or scrubbing brush

Recommended Appliances:

Mono-disc machine SRP

Neutralisation

Take up the dirty solution with well pressed-out mop-covers, or a water-suction vacuum-cleaner (e.g. Dr. Schutz Wet/Dry Vacuum-cleaner PS 27) and neutralize the floor with clear, if possible warm water, until all residues of dirt and old cleaning products have been completely removed (when the mopping water no longer foams!). Avoid pools forming and water standing.

If, subsequent to strip-cleaning, initial care, or renovation with a PU sealer product is recommended, then this strip-cleaning and the subsequent sealing with the PU Sealer product must be carried out by a specialized company with trained professionals, in accordance with the recommendations for building up resilient floors.

Maintenance Cleaning

Renovation: in the course of time, above all in areas of high traffic, the surface finish is dimi-nished or damaged. This leads to more effort needed for cleaning and is detrimental to the floor's appearance. In order to make day-to-day cleaning easier, to protect the floor and refresh its appearance, a timely renovation is necessary.

For this purpose the floor is sealed with PU Sealer /Waxnomor. This long-term sealer is extremely hard-wearing and has excellent resistance against colourless disinfectants and other colourless chemicals. The sealing work must be carried out by trained professionals from a specialist company. More details about how to prepare the subsurface appropriately and professionally, as well as sealing work can be found in our recommendations for resilient floors.

Important Notes

For glue-free floors laying floors using the click process

one cannot rule out with certainty the risk of moisture leaking into the seam areas where elements of the floor covering adjoin each other. Therefore cleaning measures which involve increased moisture should be avoided, in particular pools forming and wetness standing. The risk can be reduced by using a pressure-pump sprayer to apply the cleaning solution evenly onto the floor and working with a suitable cleaning machine. As both the removal of previous coatings and the careful cleaning before initial coating involve increased moisture, the associated potential risk should be taken into account when choosing the type of initial care beforehand, specific to the building in question.

Staining products (e.g. Hair dyes, disinfection agents) as well as softeners (e.g. coming from rubber, plastic) might lead to an irreversible discoloration of the surface. Avoid contact.

But principally our advice for all kinds of floors and sealers is to protect areas with moving chairs with suitable padded mats – in commercial as well as private areas.

Dr. Schutz°GROUP

Carpets should not be laid on the sealed surface until after about 7 days hardening.

Furniture and other furnishings should be carefully moved back into the room.

The sealed area should not be mopped wet in the first 3 days afterwards.

Adhesive tapes (e.g. for taping down covers of other manual work) should not be used until the PU Sealer has hardenend completly (after 7 days). Use only suitable adhesive tapes (e.g. Dr. Schutz Pro Tape). Unsuitable adhesive tapes or improper use can lead to the sealer becoming peeling off.

Please also pay attention to the Product Information Sheets of the above-mentioned products!

If the non-slip property of a floor (rating group R10 or higher) is to be further guaranteed, then we absolutely advise you not to apply initial care, or to renovate the floor with a polymer finish or a permanent sealer.

These cleaning and care instructions are an integral part of the general recommendations for the maintenance of the floor covering, coordinated with the floor manufacturers, taking into account the given requirements specific to the building in question. By passing on these cleaning and care instructions to his client, the floor installer fulfills the regulations of German norm DIN 18 365 for laying a new floor covering. If you have any further questions about the right cleaning and care of resilient floor coverings, or if you are interested in instructions for other floor coverings, please seek our advice on technical applications, or visit our website under www.dr-schutz.com.

Dr. Schutz GmbH
Holbeinstr. 17
D-53175 Bonn
Tel. (0228) 95352-0
www.dr-schutz.com
Advice on technical applications:
Tel. (05152) 9779-16
E-Mail technik@dr-schutz.com

With the publication of this version the previous cleaning and care instructions are super-seded and no longer valid.

Version: 06/2022