

FLOOR MAT

GB Floor Mat – For the gentle cleaning and care of vinyl, linoleum, rubber, natural and artificial stone floors. Creates a matt anti-slip protective finish. Also very suitable for the quick refreshment of floor types with a PU factory finish due to the special polymer combination. **Instructions for Use:** Initial Protection: 1) First thoroughly clean the floor with Clean and Strip. 2) Shake Floor Mat well and apply undiluted in a thin, even film using the Polish Applicator System or a non-felting wiper mop. 3) Allow the floor surface to dry overnight before it is used. 4) For some floor coverings, no care treatment is recommended. Please refer to the care instructions for the floor covering. Daily Cleaning: Add 1 graduation = 50ml Floor Mat to a bucket (8-10 litres) of water. Turn off under-floor central heating before commencing work. **Note:** When applying the product undiluted, avoid strong sunlight and drafts. Turn off under-floor central heating before commencing work. Our tip: From time to time, remove the worn protective finish with Clean and Strip and then give the floor a new care treatment with Floor Mat. **Data on ingredients:** <5% TETRAMETHYLACETYLOCTAHYDRONAPHTHALENES, preservation agents (2-BROMO-2-NITROPROPANE-1,3-DIOL, METHYLISOTHIAZOLINONE, BENZISOTHIAZOLINONE, METHYLCHLOROISOTHIAZOLINONE / METHYLISOTHIAZOLINONE), perfumes. Contains 2-methyl-2H-isothiazol-3-one, reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2-methyl-2H-isothiazol-3-one (3:1), 5-chloro-2-methyl-2H-isothiazol-3-one. May produce an allergic reaction. Keep locked up and out of the reach of children. Protect from frost. Only feed into recycling systems when clean and completely empty.

750 ml

= 30 m² (initial protection)

= 750 m² (daily cleaning)

UFI: VT90-V0F9-F00E-7THG

For further information:

www.dr-schutz.com · info@dr-schutz.com

www.terhuerne.com

Dr. Schutz GmbH

Steinbrinksweg 30 · D-31840 Hessisch Oldendorf

Tel.: +49(0)5152/9779-16

ter Hürne GmbH & Co. KG

Ramsdorfer Straße 5 · D-46354 Südlohn

Art.-Nr.: 1101060279 | GB | 2021.14